The piston ring with the bevelled profile must be fitted as the third ring from the top. Both the liner seals are black and can be fitted in any order.

> Piston ring in profile Bevelled profile

