


Instruction for ignition switch

112-14159


ANV014

EN



Connection

30	+ Supply
15/54	Ignition/Radio
50	Starter motor
57	Extra function
58/57	(Not connected)



Positions

P.	Parking position	30-57
0.	—	
1.	Ignition/Radio	30-15/54
2.	Start/Ignition/Radio	30-50-15/54

2021-10-29



Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com