


Instruction for ignition switch

Z-55115731


ANV016

EN



Connection

30	+ Supply
15	Ignition
54	Radio
56a	Main beam
56b	Dipped beam
57	Parking forward
58	Parking backward, side marker light



Positions

0.	Key removed	—	
0.	Key inserted	Ignition/Radio	30-15-54
1.	Ignition/Radio+Extra function		30-15-54-57-58
2.	Ignition/Radio+Extra function		30-15-54-56a-58
3.	Ignition/Radio+Extra function		30-15-54-56b-58

2021-10-29



Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com