


Anvisning for startlås

Z-55115731


ANV016

NO



Tilkobling

30	+Mating
15	Tenning
54	Radio
56a	Hellys
56b	Halvlys
57	Parkering forover
58	Parkering bakover, sidemarkering



Stillinger

0.	Uttrukket nøkkel	—	
0.	Inntrykt nøkkel	Tenning/Radio	30-15-54
1.	Tenning/Radio+Ekstra funksjon		30-15-54-57-58
2.	Tenning/Radio+Ekstra funksjon		30-15-54-56a-58
3.	Tenning/Radio+Ekstra funksjon		30-15-54-56b-58

2021-10-29



Olssons i Ellös AB • Tlf. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com