


Instruction for priority flow valve

58218

ANV018

EN



P	Priority flow
IN	Inlet
B	Other flow

2021-10-29



Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com