

# Instruction for ignition switch

112-14109



ANV019

EN




## Connection

30/1 + supply  
30 + supply  
15 Ignition  
15/54 Ignition + radio  
50 Starter motor



## Momentary



## Positions

0. —  
1. Ignition position/Radio 30/1-15 30-15/54  
2. Start position 30/1-15 30-15/54-50

2021-10-29



**Olsson Parts**

Olssons i Ellös AB • Tel. +46 304-751010  
Slätthultsvägen 12 • S-474 31 Ellös  
www.olssonparts.com • order@olssonparts.com