


Instruction for ignition switch

V-30100800


ANV025

EN



Connection

30	+ Supply
58	Extra function
15/54	Ignition + Radio
19	Heater plug
50	Starter motor
17	Extra function



Positions

P.	Parking position (pushed in)	30-58
0.	—	
1.	Ignition/Radio	30-15/54
2.	Heating/Ignition/Radio	30-19-15/54
3.	Start (pushed in)	30-50-15/54-17

2021-10-29