

Instruction for connecting a wireless camera

43776, 45582, 47332, 47923, 48084

ANV035

SV

Inkopplingsanvisning trådlös backkamera

För att koppla ihop en trådlös backkamera med trådlös monitor finns två tillvägagångssätt:

1. Koppla kamerans röda kabel till + matning 10 - 30 V, och kamerans svarta kabel till -. Gå in i huvudmenyn på monitorn och välj "Pairing" genom att trycka på M, sedan +/- till "Pairing" och sedan pil ner för att aktivera.
Tryck sedan in knappen "Pair" bak på kameran med hjälp av en penna eller liknande, och håll knappen intryckt i ett par sekunder.
Nedräkningen på kameran skall då avslutas och bilden skall komma upp efter 5-10 sekunder.

Alternativt kan följande sätt användas, speciellt när kameran sitter svåråtkomligt:

2. Montera kameran på vald plats, men koppla enbart in svart kabel till -. Gå in i huvudmenyn på monitorn och välj "Pairing" genom att trycka på M, sedan +/- till "Pairing" och sedan pil ner för att aktivera.
När detta är gjort, koppla då in kamerans röda kabel till + matning 10 - 30 V innan nedräkningen är avslutad, kameran hamnar då automatiskt i "pair"-läge.

Connecting a wireless camera:

To connect a wireless camera to a wireless monitor, there is two different ways:

1. Connect the cameras red wire to power + 10 - 30 V, and the black wire to ground. Go to the main menu on the monitor by pressing M, then use +/- to go to "Pairing" and activate by pressing arrow down.
Then press the "Pair" button on the backside of the camera using a pencil or similar, and hold the button pressed for a few seconds.
The countdown in the monitor will disappear and the picture will be shown within 5-10 seconds.

There is also an alternative way to proceed, especially when the camera is mounted in a place hard to reach:

2. Mount the camera in chosen position, but only connect the black wire to ground. Go to the main menu on the monitor by pressing M, then use +/- to go to "Pairing" and activate by pressing arrow down.
Now connect the red wire from the camera to + 10 - 30 V before the countdown is finished, the camera will now automatically go into "Pair"- mode

2020-03-02



Olssons i Ellös
SPAREPARTS AND EQUIPMENT

Slätthultsvägen 12 • S-474 31 Ellös
Tel. +46 304-751010 • Fax +46 304-751011
www.oie.se/www.oieparts.com • order@oie.se