


Instruction for ignition switch

D-1175809


ANV037

EN



Connection

30	+ Supply
58	Extra function
15/54	Ignition + Radio
19	Heater plug
50a	Starter motor
17	Extra function



Positions

P.	Parking position	30-58
0.	—	
1.	Ignition/Radio	30-15/54
2.	Heating/Ignition/Radio	30-19-15/54
3.	Start	30-50a-15/54-17

2021-11-08



Olsson Parts

Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com