



Anvisning for startlås

81871583


ANV049

NO



Tilkobling

1. + Mating
2. Radio
3. Glødeplugg
4. Tenning
5. Starter



Stillinger

- | | |
|------------------|-------|
| 0. — | |
| 1. Radio | 1-2 |
| 2. Tenning/Radio | 1-2-4 |
| 3. Gløding | 1-3 |
| 4. Gløding/Start | 1-3-5 |



Olsson Parts.

Olssons i Ellös AB • Tlf. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com

2021-11-08