

Anvisning for startlås

44053


ANV068

NO



Tilkobling

1. + Mating
2. Parkering
3. Tenning
4. Gløding
5. Starter



Stillinger

- | | |
|-----------------------|---------|
| 0. – | |
| 1. Parkeringsstilling | 1-2 |
| 2. Arbeidsstilling | 1-2-3 |
| 3. Glødestilling | 1-3-4 |
| 4. Startstilling | 1-3-4-5 |

2021-10-29



Olsson Parts

Olssons i Ellös AB • Tlf. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com