

Anvisning til brændstofmåler/sensor


39033 & 41204

ANV085

DA



Tilkobling

- B Strøm fra batteri (+)
- T Sluttes til polen i sensorens centrum
-  Sluttes til jord



Tilkobling

- Benet i centrum sluttes til pol T på måleren.
- Det lilla ben sluttes til jord.

2021-11-08



Olssons i Ellös AB • Tlf. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com