

Instruction for sprung comfort seat Cobo

171-1079

ANV108

EN



Control to move the seat forwards or backwards

Height setting.
Clockwise = Seat lowers
Anticlockwise = Seat raised



Setting for the spring pressure (50-130 kg).
Clockwise = Harder
Anticlockwise = Softer

2021-11-08



Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com

