



The compressors we sell are supplied with a small quantity of delivery oil that needs to be drained and replaced with the right type and quantity according to the vehicle manufacturer's recommendations.

The following points must be carried out during a compressor replacement for the warranty to be valid:

1. Check that the compressor is filled with the right quantity and the right type of oil before assembly.
2. Replace the drying filter.
3. Rinse the system thoroughly with an approved rinsing agent/solvent as per the approved method.
4. Check that there is no dirt or chips in the expansion valve. Replace if it does not work correctly.
5. Only refrigerant R134a (replacement for R12) may be used.
6. Only certified persons may perform this work.

The aforementioned points must be documented in the event of warranty claims.

