


Instruction for hydraulically controlled brake valve

Round pumping system

EN



Ports	Thread
P	M22 x 1,5
N	M22 x 1,5
B	M22 x 1,5
T	M22 x 1,5
Y	M12 x 1,5

2021-11-08




Olsson Parts

Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com

Instruction for hydraulically controlled brake valve for John Deere

Constant pressure system

EN



Ports	Thread
P	M22 x 1,5
N	M22 x 1,5
B	M22 x 1,5
T	M22 x 1,5
Y	M12 x 1,5

2021-11-08




Olsson Parts

Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com

Instruction for hydraulically controlled brake valve for LS system

EN



Ports	Thread
P	M22 x 1,5
N	M22 x 1,5
B	M22 x 1,5
T	M22 x 1,5
Y	M12 x 1,5

2021-11-08



Olsson Parts

Olssons i Ellös AB • Tel. +46 304-751010
 Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com