


Instruction for priority flow valve

55591

ANV174

EN

Priority flow 0-40 l/min. Knob adjustment.



2021-11-08



Olsson Parts

Olssons i Ellös AB • Tel. +46 304-751010
Slätthultsvägen 12 • S-474 31 Ellös
www.olssonparts.com • order@olssonparts.com