


# Instruction for priority flow valve

55592

ANV175

EN

Priority flow 0-100 l/min. Knob adjustment.



2021-11-08



**Olsson Parts**

Olssons i Ellös AB • Tel. +46 304-751010  
Slätthultsvägen 12 • S-474 31 Ellös  
www.olssonparts.com • order@olssonparts.com