





30-51 er indkoblet,
når låsen bruges som
tændingslås.
Andre forbindelser
bruges til belysning.

Tilkobling

30. + tilførsel
30/1 + tilførsel



Stillinger

P. 30/1 - 58

0.

1. 30-51

2. 30-51 30/1 - 58

3. 30-51 30/1 - 58-56B

4. 30-51 30/1 - 58-56A

