

Anvisning til skifteventil

39816 & 38277

ANV220



DA



39816



38277



Upåvirket magnet

P1 - C2

P2 - C3

P3 - C6

P4 - C7

Påvirket magnet

P1 - C1

P2 - C4

P3 - C5

P4 - C8

2021-11-08

